

TIGER 280
DUAL DRIVE ROTARY TILLER

TIGER
280 DD

093.359.0

SPARE PARTS CATALOGUE






2 SPEED GEARBOX

2 SPEED GEARBOX

Tav. Tab. Taf.	359849	Rev.	00	0706
----------------------	---------------	------	-----------	-------------

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	013034	Pin	25	661108	Cover	48	011003	Grower
2	423713	Nut	26	013027	Pin	49	010006	Washer
3	422647	Gear	27	423714	Nut	50	007151	Oil seal
4	003132S	Bearing	28	003131S	Bearing	51	004072	Nut
5	007225	Oil seal	29	422560	Spacer			
6	007154	Gasket	30	423281	Gear			
7	014145	Screw		423279	Gear			
400 8	461363	Spacer		423276	Gear			
450	461360	Spacer		423277	Gear			
500	461361	Spacer		423269	Gear			
9	422563	Spacer		423272	Gear			
10	014205	Screw		423273	Gear			
11	422550	Cover		423286	Gear			
12	003145S	Bearing	31	422559	Spacer			
13	462150	Housing	32	014149	Screw			
14	421768	Cover	400 33	423869	Axle shaft			
15	022150	Plug	450	423810	Axle shaft			
16	423285	Gear	500	423811	Axle shaft			
	423270	Gear	34	001168	Set spacers			
	423271	Gear		001169	Set spacers			
	423268	Gear	35	022167	Plug			
	423274	Gear	36	014284	Screw			
	423275	Gear	37	010023	Washer			
	423278	Gear	38	014007	Screw			
	423280	Gear	39	011002	Grower			
17	423798	Spacer	40	411486	Guard			
18	014214	Screw	41	161500	Support			
19	423796	Shaft	42	013055	Pin			
20	462152	Cover	43	424513	Gasket			
21	007224	Oil seal	44	094002	Glue			
22	422551	Cover	45	014182	Screw			
23	022168	Plug	46	022087	Washer			
24	323644	Spacer	47	014150	Screw			



TRANSMISSION

Tav.
Tab.
Taf.


359850

Rev.

00 0706

TRANSMISSION

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	411602	Dust cover	34	611710	Set spacers	63	723519	Spacer
2	011005	Grower	35	723518	Spacer	64	724507	Gasket
3	014200	Screw	36	411863	Spacer	65	423714	Nut
4	422538	Tine	37	014402	Screw	66	011036	Washer
5	007054	Gasket	38	411600	Dust cover	67	461158	L.H. Tine Rotor
6	003006S	Bearing	39	422620	Hub		461390	L.H. Tine Rotor
7	005011	Ring nut	40	871504	Oil seal		461391	L.H. Tine Rotor
8	014311	Screw	41	422625	L.H. support		461159	R.H. Tine Rotor
9	722526	Cover	42	411601	Dust cover		461395	R.H. Tine Rotor
10	014082	Screw	43	007153	Gasket		461396	R.H. Tine Rotor
11	004084	Nut	44	422626	R.H. support			
12	011003	Grower	45	461193	Rotor R			
13	004058	Nut		461194	Rotor R			
14	011002	Grower		461195	Rotor R			
15	722534	Blade	46	722537	Right helicoidal blade			
16	022167	Plug	47	011004	Grower			
17	014248	Screw	48	004011	Nut			
18	461460	Cover	49	461154	Knife type drum			
19	014149	Screw		461425	Knife type drum			
20	022009	Plug		461426	Knife type drum			
21	013027	Pin	50	771563	Flange kit			
22	723523	Nut		771564	Flange kit			
23	014278	Screw	51	722538	Left helicoidal blade			
24	003115S	Bearing	52	722533	Blade			
25	722514	Gear	53	422631	L.H. Knife			
26	003133S	Bearing	54	422630	R.H. Knife			
27	001034	Stop ring	55	004072	Nut			
28	422649	Gear	56	014222	Screw			
29	411511	Washer	57	014261	Screw			
30	094002	Glue	58	712608	Flange			
31	422621	Drive hub	59	007011	Gasket			
32	423786	Pivot	60	014213	Screw			
33	004030	Nut	61	021082	Column			
			62	002018	Split pin			




DX mod. 400 - 450

RH FRAME GROUP

Tav. Tab. Taf.	359962	Rev.	00	1107
----------------------	---------------	------	-----------	-------------

RH FRAME GROUP

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	014254	Screw	450 28	461187	Central impeller extension
2	014212	Screw	500	462267	Central impeller extension
3	461411	R.H. side shield	500	462268	Central impeller extension
4	014082	Screw	29	461109	R.H. side shield
5	014147	Screw	30	412376	Central blade
6	462179	R.H. skid	31	011004	Grower
7	010002	Washer	32	014011	Screw
8	004054	Nut	33	014083	Screw
9	423363	Rod	34	423873	Bush
10	014019	Screw	35	004054	Nut
11	423361	Support	36	611427	Plate
12	014004	Screw	37	611409	Spacer
13	014149	Screw	38	014084	Screw
14	011002	Grower	39	461473	Plate
15	014382	Screw	40	014382	Screw
16	466490	Right impeller extension	41	011003	Grower
17	004087	Nut	42	004087	Nut
18	411860	Plate	43	014087	Screw
400 19	423626	Pivot	44	004072	Nut
450	423627	Pivot	45	471442	Screw
500	423628	Pivot			
400 20	466560	R.H. rear shield			
450	466577	R.H. rear shield			
500	466578	R.H. rear shield			
21	011004	Grower			
22	004004	Nut			
23	010006	Washer			
24	004072	Nut			
25	623572	Support			
26	014285	Screw			
400 27	461112	R.H. frame			
450	461113	R.H. frame			
500	461114	R.H. frame			
400 28	461187	Central impeller extension			




SX mod. 400 - 450

LH FRAME GROUP

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	014254	Screw	450 28	461187	Central impeller extension
2	014212	Screw	500	462267	Central impeller extension
3	461409	L.H. side shield	500	462268	Central impeller extension
4	014082	Screw	29	461108	L.H. side shield
5	014147	Screw	30	412376	Central blade
6	462098	L.H. skid	31	011004	Grower
7	010002	Washer	32	014011	Screw
8	004054	Nut	33	014083	Screw
9	423363	Rod	34	423873	Bush
10	014019	Screw	35	004054	Nut
11	423361	Support	36	611427	Plate
12	014004	Screw	37	611409	Spacer
13	014149	Screw	38	014084	Screw
14	011002	Grower	39	461473	Plate
15	014382	Screw	40	014382	Screw
16	466491	Left impeller extension	41	011003	Grower
17	004087	Nut	42	004087	Nut
18	411860	Plate	43	014087	Screw
400 19	423626	Pivot	44	004072	Nut
450	423627	Pivot	45	471442	Screw
500	423628	Pivot			
400 20	466550	L.H. rear shield			
450	466558	L.H. rear shield			
500	466559	L.H. rear shield			
21	011004	Grower			
22	004004	Nut			
23	010006	Washer			
24	004072	Nut			
25	623572	Support			
26	014285	Screw			
400 27	461132	L.H. frame			
450	461133	L.H. frame			
500	461134	L.H. frame			
400 28	461187	Central impeller extension			

SX mod. 400 - 450



LH FRAME GROUP

Tav.
Tab.
Taf.



359977

Rev.

00 1107

LH FRAME GROUP

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODICE	DENOMINATION
1	014212	Screw	30	004079	Nut
2	461409	L.H. side shield	400 31	661164	L.H. rear shield
3	423873	Bush	450	661163	L.H. rear shield
4	011004	Grower	500	661162	L.H. rear shield
5	461456	Protection	32	923505	Spring
6	014254	Screw	33	002014	Split pin
7	014149	Screw	34	423558	Pivot
8	011002	Grower	35	010012	Washer
9	461027	L.H. side clod bumper	36	923587	Support
10	411860	Plate	37	010009	Washer
400 11	423626	Pivot	38	004073	Nut
450	423627	Pivot	39	461471	Handle wrench
500	423628	Pivot	40	412596	Arm
12	004004	Nut	41	014229	Screw
13	014285	Screw	42	014213	Screw
400 14	461132	L.H. frame	43	004035	Nut
450	461133	L.H. frame	44	423557	Spring
500	461134	L.H. frame	45	014011	Screw
15	010006	Washer	46	011004	Grower
16	623572	U-bolt	47	412376	Central blade
17	014083	Screw	48	004030	Nut
18	004072	Nut	49	011003	Grower
19	611427	Plate	50	423560	Support
20	014084	Screw	51	422529	Adjusting bar
21	611409	Spacer	52	014145	Screw
22	014019	Screw	53	411524	Hinge
23	014199	Screw	54	014257	Screw
24	471442	Screw			
25	461108	L.H. side shield			
26	661145	Pivot			
27	423769	Bush			
28	014382	Screw			
29	461129	Central extension			
	461318	L.H. extension			



RH FRAME GROUP

Tav.
Tab.
Taf.


357978

Rev.

00 1107

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	014212	Screw	30	004079	Nut
2	461411	R.H. side shield	400 31	661174	R.H. rear shield
3	423873	Bush	450	661173	R.H. rear shield
4	011004	Grower	500	661172	R.H. rear shield
5	461455	Protection	32	923505	Spring
6	014254	Screw	33	002014	Split pin
7	014149	Screw	34	423558	Pivot
8	011002	Grower	35	010012	Washer
9	461026	R.H. side clod bumper	36	923587	Support
10	411860	Plate	37	010009	Washer
400 11	423626	Pivot	38	004073	Nut
450	423627	Pivot	39	461471	Handle wrench
500	423628	Pivot	40	412596	Arm
12	004004	Nut	41	014229	Screw
13	014182	Screw	42	014213	Screw
400 27	461112	R.H. frame	43	004035	Nut
450	461113	R.H. frame	44	423557	Spring
500	461114	R.H. frame	45	014011	Screw
15	010006	Washer	46	011004	Grower
16	623572	U-bolt	47	412376	Central blade
17	014083	Screw	48	004030	Nut
18	004072	Nut	49	011003	Grower
19	611427	Plate	50	423560	Support
20	014084	Screw	51	422529	Adjusting bar
21	611409	Spacer	52	014145	Screw
22	014019	Screw	53	411524	Hinge
23	014199	Screw	54	014257	Screw
24	471442	Screw			
25	461109	R.H. side shield			
26	661145	Pivot			
27	423769	Bush			
28	014382	Screw			
29	461129	Central extension			
	461317	R.H. extension			

mod. 400 - 450



CENTRE FRAME

Tav.
Tab.
Taf.


359963

Rev.

00

1107

RIF.	N. CODICE	DENOMINATION
1	014007	Screw
2	011002	Grower
3	612727	Flange
4	099140	Guard
5	471441	Housing
6	011005	Grower
7	014326	Screw
8	461198	Swinging arm (cat.III)
9	423091	Bushing
10	013011	Pin
11	423871	Pivot
12	423283	Pivot
13	014355	Screw
14	010003	Washer
15	004077	Nut
16	461148	Support
17	014019	Screw
18	010002	Washer
19	004004	Nut
20	461149	Third point
	461166	Third point
21	423781	Pivot
22	423779	Bushing
23	523654	Drive shaft hook
24	004055	Nut
25	611728	Flask
26	010023	Washer
27	011032	Grower
28	010004	Washer
29	411428	Support
30	411429	Protection
31	014001	Screw
32	014005	Screw



CAGE ROLLER Ø 500

Tav.
Tab.
Taf.**359188**

Rev.

00 1107


CAGE ROLLER Ø 500

Tav.
Tab.
Taf.**359188**

Rev.

00**1107**

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	011004	Grower	33	004072	Nut
2	411529	Plate	34	661402	Plate
3	423833	Spacer	35	411528	Plate
4	014082	Screw	36	423790	R.H. Attach. arm fulcrum lug
5	014019	Screw		998230	Cage roller
6	014398	Screw		998231	Cage roller
7	004004	Nut			
8	423769	Bush			
9	014399	Screw			
10	423791	L.H. Attach. arm fulcrum lug			
11	014004	Screw			
12	010006	Washer			
13	010002	Washer			
400 14	462401	Bar			
450	462402	Bar			
15	611436	Arm			
16	612372	Plate			
17	013019	Pin			
18	014254	Screw			
19	661401	Stub axle			
20	004030	Nut			
400 21	961950	Cage roller			
450	961951	Cage roller			
22	004054	Nut			
23	661403	Bush			
24	462011	Arm			
25	099018	Dust cover			
26	008005	Grease nipple			
27	421604	Support			
28	003051	Bearing			
29	001006	Stop ring			
30	014145	Screw			
31	011003	Grower			
32	014192	Screw			



LH CAGE ROLLER Ø 500


LH CAGE ROLLER Ø 500

Tav.
Tab.
Taf.**359189**

Rev.

00 1107

RIF.	N. CODICE	DENOMINATION
1	011004	Grower
2	411529	Plate
3	423833	Spacer
4	014082	Screw
5	014019	Screw
6	014398	Screw
7	004004	Nut
8	423769	Bush
9	014399	Screw
10	423791	L.H. Attach. arm fulcrum lug
11	014004	Screw
12	010006	Washer
13	010002	Washer
500	14	462403 Bar
	15	611436 Arm
	16	612372 Plate
	17	013019 Pin
	18	014254 Screw
	19	661401 Stub axle
	20	004030 Nut
500	21	961952 Cage roller
	22	004054 Nut
	23	661403 Bush
	24	462011 Arm
	25	099018 Dust cover
	26	008005 Grease nipple
	27	421604 Support
	28	003051 Bearing
	29	001006 Stop ring
	30	014145 Screw
	31	011003 Grower
	32	014192 Screw
	33	004072 Nut
	34	661402 Plate
500	998232	Cage roller



RH CAGE ROLLER Ø 500

Tav.
Tab.
Taf.**359190**

Rev.

00 1107


RH CAGE ROLLER Ø 500

Tav.
Tab.
Taf.**359190**

Rev.

00**1107**

RIF.	N. CODICE	DENOMINATION	
1	011004	Grower	
2	411528	Plate	
3	423833	Spacer	
4	014082	Screw	
5	014019	Screw	
6	014398	Screw	
7	004004	Nut	
8	423769	Bush	
9	014399	Screw	
10	423790	R.H. Attach. arm fulcrum lug	
11	014004	Screw	
12	010006	Washer	
13	010002	Washer	
500	14	462413	Bar
15	661141	Arm	
16	612372	Plate	
17	013019	Pin	
18	014254	Screw	
19	661401	Stub axle	
20	004030	Nut	
500	21	961952	Cage roller
22	004054	Nut	
23	661403	Bush	
24	411470	Arm	
25	099018	Dust cover	
26	008005	Grease nipple	
27	421604	Support	
28	003051	Bearing	
29	001006	Stop ring	
30	014145	Screw	
31	011003	Grower	
32	014192	Screw	
33	004072	Nut	
34	661402	Plate	
500	998232	Cage roller	



PACKER ROLLER Ø 555


PACKER ROLLER Ø 555

Tav.
Tab.
Taf.**359191**

Rev.

00**1107**

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	011004	Grower	32	014192	Screw
2	411529	Plate	33	004072	Nut
3	423833	Spacer	34	661402	Plate
4	014082	Screw	35	612372	Plate
5	014019	Screw	36	412782	Tine (to be welded)
6	014398	Screw	37	961910	Scratcher support
7	004004	Nut		961911	Scratcher support
8	423769	Bush	38	014386	Screw
9	014399	Screw	39	911601	Scraper
10	423791	L.H. Attach. arm fulcrum lug	40	004003	Nut
11	014004	Screw	41	014214	Screw
12	010006	Washer	42	911629	Scraper
13	010002	Washer	43	411528	Plate
400	14	462401	44	423790	R.H. Attach. arm fulcrum lug
450		462402	400	998240	Packer roller
	15	411470	450	998241	Packer roller
	16	911630			
	17	013019			
	18	014145			
	19	661401			
	20	004084			
400	21	961920			
450		961921			
	22	004054			
	23	661403			
	24	462011			
	25	099018			
	26	008005			
	27	421604			
	28	003051			
	29	001006			
	30	014145			
	31	011033			



LH PACKER ROLLER Ø 555


LH PACKER ROLLER Ø 555

Tav.
Tab.
Taf.**359192**

Rev.

00 1107

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	011004	Grower	34	661402	Plate
2	411529	Plate	35	612372	Plate
3	423833	Spacer	36	412782	Tine (to be welded)
4	014082	Screw	37	961912	Scratcher support
5	014019	Screw	38	014386	Screw
6	014398	Screw	39	911601	Scraper
7	004004	Nut	40	004003	Nut
8	423769	Bush	41	014214	Screw
9	014399	Screw	42	911629	Scraper
10	423791	L.H. Attach. arm fulcrum lug	500	998242	Packer roller
11	014004	Screw			
12	010006	Washer			
13	010002	Washer			
500	14	462403			
	15	411470			
	16	911630			
	17	013019			
	18	014145			
	19	661401			
	20	004084			
500	21	961922			
	22	004054			
	23	661403			
	24	462011			
	25	099018			
	26	008005			
	27	421604			
	28	003051			
	29	001006			
	30	014145			
	31	011033			
	32	014192			
	33	004072			



RH PACKER ROLLER Ø 555

Tav.
Tab.
Taf.**359193**

Rev.

00**1107**


RH PACKER ROLLER Ø 555

Tav.
Tab.
Taf.**359193**

Rev.

00 1107

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	011004	Grower	34	661402	Plate
2	423833	Spacer	35	612372	Plate
3	423833	Spacer	36	412782	Tine (to be welded)
4	014082	Screw	37	961912	Scratcher support
5	014019	Screw	38	014386	Screw
6	014398	Screw	39	911601	Scraper
7	004004	Nut	40	004003	Nut
8	423769	Bush	41	014214	Screw
9	014399	Screw	42	911629	Scraper
10	423790	R.H. Attach. arm fulcrum lug		998242	Packer roller
11	014004	Screw			
12	010006	Washer			
13	010002	Washer			
500	14	462413			
	15	462014			
	16	911630			
	17	013019			
	18	014145			
	19	661401			
	20	004084			
500	21	961922			
	22	004054			
	23	661403			
	24	411470			
	25	099018			
	26	008005			
	27	421604			
	28	003051			
	29	001006			
	30	014145			
	31	011033			
	32	014192			
	33	004072			



SPIRAL ROLLER Ø 470


SPIRAL ROLLER Ø 470

Tav.
Tab.
Taf.**359194**

Rev.

00**1107**

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	011004	Grower	31	011003	Grower
2	411529	Plate	32	014192	Screw
3	423833	Spacer	33	004072	Nut
4	014082	Screw	34	661402	Plate
5	014019	Screw	35	411528	Plate
6	014398	Screw	36	423790	R.H. Attach. arm fulcrum lug
7	004004	Nut	400	998280	Spiral roller
8	423769	Bush	450	998281	Spiral roller
9	014399	Screw			
10	423791	L.H. Attach. arm fulcrum lug			
11	014004	Screw			
12	010006	Washer			
13	010002	Washer			
400	14	462401			
450		462402			
	15	411470			
	16	612372			
	17	013019			
	18	014145			
	19	661401			
400	20	961820			
450		961821			
400	21	961980			
450		961981			
	22	004054			
	23	661403			
	24	462011			
	25	099018			
	26	008005			
	27	421604			
	28	003051			
	29	001006			
	30	014145			



LH SPIRAL ROLLER Ø 470


LH SPIRAL ROLLER Ø 470

Tav.
Tab.
Taf.**359195**

Rev.

00**1107**

RIF.	N. CODICE	DENOMINATION
1	011004	Grower
2	411529	Plate
3	423833	Spacer
4	014082	Screw
5	014019	Screw
6	014398	Screw
7	004004	Nut
8	423769	Bush
9	014399	Screw
10	423791	L.H. Attach. arm fulcrum lug
11	014004	Screw
12	010006	Washer
13	010002	Washer
500	14	462403 Bar
15	411470	Arm
16	612372	Plate
17	013019	Pin
18	014145	Screw
19	661401	Stub axle
500	20	961822 Scratcher support
500	21	961982 Spiral roller
22	004054	Nut
23	661403	Bush
24	462011	Arm
25	099018	Dust cover
26	008005	Grease nipple
27	421604	Support
28	003051	Bearing
29	001006	Stop ring
30	014145	Screw
31	011003	Grower
32	014192	Screw
33	004072	Nut
34	661402	Plate
500	998282	Spiral roller



RH SPIRAL ROLLER Ø 470

Tav.
Tab.
Taf.**357167**

Rev.

00 0206

RH SPIRAL ROLLER Ø 470

Tav.
Tab.
Taf.


357167

Rev.

00

0206

RIF.	N. CODICE	DENOMINATION	
1	011004	Grower	
2	411528	Plate	
3	423833	Spacer	
4	014082	Screw	
5	014019	Screw	
6	014398	Screw	
7	004004	Nut	
8	423769	Bush	
9	014399	Screw	
10	423790	R.H. Attach. arm fulcrum lug	
11	014004	Screw	
12	010006	Washer	
13	010002	Washer	
500	14	462413	Bar
15	661141	Arm	
16	612372	Plate	
17	013019	Pin	
18	014145	Screw	
19	661401	Stub axle	
500	20	961822	Scratcher support
500	21	961982	Spiral roller
22	004054	Nut	
23	661403	Bush	
24	411470	Arm	
25	099018	Dust cover	
26	008005	Grease nipple	
27	421604	Support	
28	003051	Bearing	
29	001006	Stop ring	
30	014145	Screw	
31	011003	Grower	
32	014192	Screw	
33	004072	Nut	
34	661402	Plate	
500	998282	Spiral roller	



SPIKES ROLLER Ø 560


SPIKES ROLLER Ø 560

Tav.
Tab.
Taf.**359197**

Rev.

00 1107

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	011004	Grower	32	014192	Screw
2	411529	Plate	33	004072	Nut
3	423833	Spacer	34	661406	Plate
4	014082	Screw	35	612372	Plate
5	014019	Screw	36	913704	Tine (to be welded)
6	014398	Screw	37	623750	U bolt
7	004004	Nut	400 38	961850	Scratcher support
8	423769	Bush	450	961851	Scratcher support
9	014399	Screw	39	961818	Scraper
10	423791	L.H. Attach. arm fulcrum lug	40	411528	Plate
11	014004	Screw	41	423790	R.H. Attach. arm fulcrum lug
12	010006	Washer	400	998270	Spikes roller
13	010002	Washer	450	998271	Spikes roller
400 14	462401	Bar			
450	462402	Bar			
15	411470	Arm			
16	911602	Plate			
17	013019	Pin			
18	014145	Screw			
19	661401	Stub axle			
20	004101	Nut			
400 21	961990	Spikes roller			
450	961991	Spikes roller			
22	004054	Nut			
23	661403	Bush			
24	462011	Arm			
25	099018	Dust cover			
26	008005	Grease nipple			
27	421604	Support			
28	003051	Bearing			
29	001006	Stop ring			
30	014145	Screw			
31	011003	Grower			



LH SPIKES ROLLER Ø 560


Tav.
Tab.
Taf.**359198**

Rev.

00**1107**

LH SPIKES ROLLER Ø 560

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	011004	Grower	34	661406	Plate
2	411529	Plate	35	612372	Plate
3	423833	Spacer	36	913704	Tine (to be welded)
4	014082	Screw	37	623750	U bolt
5	014019	Screw	38	961852	Scratcher support
6	014398	Screw	39	961818	Scraper
7	004004	Nut		998272	Spikes roller
8	423769	Bush			
9	014399	Screw			
10	423791	L.H. Attach. arm fulcrum lug			
11	014004	Screw			
12	010006	Washer			
13	010002	Washer			
500	14	462403			
	15	411470			
	16	911602			
	17	013019			
	18	014145			
	19	661401			
	20	004101			
500	21	961992			
	22	004054			
	23	661403			
	24	462011			
	25	099018			
	26	008005			
	27	421604			
	28	003051			
	29	001006			
	30	014145			
	31	011003			
	32	014192			
	33	004072			



RH SPIKES ROLLER Ø 560


RH SPIKES ROLLER Ø 560

Tav.
Tab.
Taf.**359199**

Rev.

00**1107**

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	011004	Grower	34	661406	Plate
2	411528	Plate	35	612372	Plate
3	423833	Spacer	36	913704	Tine (to be welded)
4	014082	Screw	37	623750	U bolt
5	014019	Screw	38	961852	Scratcher support
6	014398	Screw	39	961818	Scraper
7	004004	Nut		998272	Spikes roller
8	423769	Bush			
9	014399	Screw			
10	423790	L.H. Attach. arm fulcrum lug			
11	014004	Screw			
12	010006	Washer			
13	010002	Washer			
500	14	462403			
	15	462014			
	16	911602			
	17	013019			
	18	014145			
	19	661401			
	20	004101			
500	21	961992			
	22	004054			
	23	661403			
	24	411470			
	25	099018			
	26	008005			
	27	421604			
	28	003051			
	29	001006			
	30	014145			
	31	011003			
	32	014192			
	33	004072			



HYDRAULIC SYSTEM FOR ROLLER LIFTING


HYDRAULIC SYSTEM FOR ROLLER LIFTING

Tav.
Tab.
Taf.**359588**

Rev.

00**1107**

RIF.	N. CODICE	DENOMINATION	
1	022082	Shap-on coupling	
2	022087	Washer	
3	023178	Hose	
4	022129	Connection	
500	5	023154	Hose
6	021073	Flow divider	
7	462265	Connection block	
8	023153	Hose	
9	022175	Screw	
10	022070	Screw	
11	022120	Connection	
12	021094	Stop valve	
13	004072	Nut	
14	022178	Connection	
15	471444	Complete jack	
16	023152	Hose	
17	014398	Screw	
18	621736	Hose	
19	022086	Washer	
20	014122	Screw	



HYDRAULIC SYSTEM FOR ROLLER LIFTING

Tav.
Tab.
Taf.

359587

Rev.

00

1107


HYDRAULIC SYSTEM FOR ROLLER LIFTING

Tav.
Tab.
Taf.**359587**

Rev.

00**1107**

RIF.	N. CODICE	DENOMINATION	
1	022082	Shap-on coupling	
2	022087	Washer	
3	023178	Hose	
4	022129	Connection	
500	5	023154	Hose
6	021073	Flow divider	
7	462265	Connection block	
8	023153	Hose	
9	022175	Screw	
10	022070	Screw	
11	022120	Connection	
12	021094	Stop valve	
13	004072	Nut	
14	022178	Connection	
15	471444	Complete jack	
16	023152	Hose	
17	014398	Screw	
18	621736	Hose	
19	022086	Washer	
20	014122	Screw	



HYDRAULIC RAMS KIT FOR TAILGATE ADJUSTMENT


HYDRAULIC RAMS KIT FOR TAILGATE ADJUSTMENT

Tav. Tab. Taf.	359589	Rev.	00	1107
----------------------	---------------	------	-----------	-------------

RIF.	N. CODICE	DENOMINATION
1	022082	Shap-on coupling
2	022087	Washer
3	023064	Hose
4	022085	Washer
5	022104	Connection
6	022088	Connection
7	014307	Screw
8	021092	Stop valve
9	004073	Nut
10	010009	Washer
11	923587	Support
12	923505	Spring
13	010012	Washer
14	471445	Complete jack
15	022086	Washer
16	023193	Hose
17	022175	Screw
	971779	Hydraulic rams kit

COOLING KIT

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	027001	Cable	34	423605	Pulley
2	021055	Exchange	35	223405	Spacer
3	004055	Nut	36	021083	Trasmission belt
4	461107	Cover	37	423606	Pulley
5	022087	Washer	38	014320	Screw
6	023182	Hose	39	014007	Screw
7	022030	Capstan screw	40	011032	Grower
8	014001	Screw	41	010004	Washer
9	661110	Air duct	42	014026	Screw
10	099124	Screw shock absorber		971058	Cooling kit
11	010023	Washer			
12	023086	Connection			
13	021061	Thermostat			
14	023115	Hose			
15	022119	Connection			
16	021052	Filter			
17	014005	Screw			
18	011001	Grower			
19	022121	Connection			
20	023175	Hose			
21	022120	Connection			
22	023181	Hose			
23	022159	Connection			
24	004083	Nut			
25	010015	Washer			
26	021079	Hub			
27	021078	Support			
28	021051	Pump			
29	014393	Screw			
30	461107	Support			
31	014306	Screw			
32	011009	Grower			
33	010035	Washer			



CONVEYOR DISC


CONVEYOR DISC

Tav.
Tab.
Taf.**138110**

Rev.

01 0202

RIF.	N. CODICE	DENOMINATION
1	004063	Nut
2	010006	Washer
3	923690	Plate
4	014241	Screw
5	923511	U bolt
6	961693	Support
7	010009	Washer
8	002014	Split pin
9	004080	Nut
10	015008	Cover
11	961697	Support
12	003087	Bearing
13	002013	Split pin
14	961524	Drive hub
15	099017	Dust cover
16	001031	Stop ring
17	003073	Bearing
18	008002	Grease nipple
19	011002	Washer
20	004002	Nut
21	014155	Screw
22	099030	Disc
23	961696	Support
	971511	Front conveyor disc




ROLLER ADJUSTMEN JACK

ROLLER ADJUSTMEN JACK

Tav. Tab. Taf.	120221	Rev.	00	1000
----------------------	---------------	------	-----------	-------------

RIF.	N. CODICE	DENOMINATION
1	623818	Fork
2	011010	Grower
3	004027	Nut
4	662543	Ring nut
5	007177	Gasket
6	007178	Gasket
7	662545	Guide
8	007168	Gasket OR
9	423239	Rod
10	423197	Half piston
11	007165	Gasket
12	007058	Gasket OR
13	423196	Piston
14	004072	Nut
15	461464	Cylinder
16	471444	Complete jack

**LOOSENING TINE**Tav.
Tab.
Taf.**138111**


Rev.

00**0699**

LOOSENING TINE

Tav. Tab. Taf.	138111	Rev.	00	0699
----------------------	---------------	------	-----------	-------------

RIF.	N. CODICE	DENOMINATION
1	923511	U bolt
2	961510	Support
3	099027	Arm
4	011003	Washer
5	002014	Split pin
6	923510	Pivot
7	010006	Washer
8	004072	Nut
9	099028	Ripper leg
10	014354	Screw + nut
11	099029	Blade
	471708	Loosening tine



SAFETY PROTECTION

Tav. Tab. Taf.	359600	Rev.	00	1107
----------------------	---------------	------	-----------	-------------

SAFETY PROTECTION

Tav.
Tab.
Taf.

359600

Rev.

00

1107

RIF.	N. CODICE	DENOMINATION
400	1	462002 Protection
450		462003 Protection
500		462004 Protection
	2	913022 U bolt
	3	010004 Washer
	4	004066 Nut
400		978721 Protection
450		978722 Protection
500		978723 Protection