


**TIGER 280
FOLDING ROTARY TILLER**

**TIGER 280 P
TIGER 280 PF**

093.357.1

SPARE PARTS CATALOGUE





2 SPEED GEARBOX

2 SPEED GEARBOX

Tav.
Tab.
Taf.


357845

Rev.

00

0206

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	013034	Pin	25	661108	Cover	48	011003	Grower
2	423713	Nut	26	013027	Pin	49	010006	Washer
3	422647	Gear	27	423714	Nut	50	007151	Oil seal
4	003132S	Bearing	28	003131S	Bearing	51	004072	Nut
5	007225	Oil seal	29	422560	Spacer			
6	007154	Gasket	30	423281	Gear			
7	014145	Screw		423279	Gear			
450 8	461360	Spacer		423276	Gear			
500	461361	Spacer		423277	Gear			
550	461362	Spacer		423269	Gear			
9	422563	Spacer		423272	Gear			
10	014205	Screw		423273	Gear			
11	422550	Cover		423286	Gear			
12	003145S	Bearing	31	422559	Spacer			
13	462150	Housing	32	014149	Screw			
14	421768	Cover	450 33	423810	Axle shaft			
15	022150	Plug	500	423811	Axle shaft			
16	423285	Gear	550	423812	Axle shaft			
	423270	Gear	34	001168	Set spacers			
	423271	Gear		001169	Set spacers			
	423268	Gear	35	022167	Plug			
	423274	Gear	36	014284	Screw			
	423275	Gear	37	010023	Washer			
	423278	Gear	38	014007	Screw			
	423280	Gear	39	011002	Grower			
17	423798	Spacer	40	411486	Guard			
18	014214	Screw	41	161500	Support			
19	423796	Shaft	42	013055	Pin			
20	462152	Cover	43	424513	Gasket			
21	007224	Oil seal	44	094002	Glue			
22	422551	Cover	45	014182	Screw			
23	022168	Plug	46	022087	Washer			
24	323644	Spacer	47	014150	Screw			



TRANSMISSION

Tav.
Tab.
Taf.

357846

Rev.

01 0807

TRANSMISSION


Tav.
Tab.
Taf.

357846

Rev.

01 0807

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION	RIF.	N. CODI	DENOMINATION	
1	411602	Dust cover	34	611710	Set spacers	63	723519	Spacer	
2	011005	Grower	35	723518	Spacer	64	724507	Gasket	
3	014200	Screw	36	411863	Spacer	65	423714	Nut	
4	422538	Tine	37	014402	Screw	66	011036	Washer	
5	007054	Gasket	38	411600	Dust cover	450	67	461390	L.H. Tine Rotor
6	003006S	Bearing	39	422620	Hub		500	461391	L.H. Tine Rotor
7	005011	Ring nut	40	871504	Oil seal		550	461392	L.H. Tine Rotor
8	014311	Screw	41	422625	L.H. support		450	461395	R.H. Tine Rotor
9	722526	Cover	42	411601	Dust cover	500	461396	R.H. Tine Rotor	
10	014082	Screw	43	007153	Gasket	550	461397	R.H. Tine Rotor	
11	004084	Nut	44	422626	R.H. support	68	014254	Screw	
12	011003	Grower	450	461194	Rotor R	69	010004	Washer	
13	004058	Nut	500	461195	Rotor R	70	004079	Nut	
14	011002	Grower	550	461196	Rotor R				
15	722534	Blade	46	722537	Right helicoidal blade				
16	022167	Plug	47	011004	Grower				
17	014248	Screw	48	004011	Nut				
18	461460	Cover	450	461425	Knife type drum				
19	014149	Screw	500	461426	Knife type drum				
20	022009	Plug	550	461427	Knife type drum				
21	013027	Pin	50	771563	Flange kit				
22	723523	Nut		771564	Flange kit				
23	014278	Screw	51	722538	Left helicoidal blade				
24	003115S	Bearing	52	722533	Blade				
25	722514	Gear	53	422631	L.H. Knife				
26	003133S	Bearing	54	422630	R.H. Knife				
27	001034	Stop ring	55	004072	Nut				
28	422649	Gear	56	014222	Screw				
29	411511	Washer	57	014261	Screw				
30	094002	Glue	58	712608	Flange				
31	422621	Drive hub	59	007011	Gasket				
32	423786	Pivot	60	014213	Screw				
33	004030	Nut	61	021082	Column				
			62	002018	Split pin				



LH FRAME GROUP

Tav.
Tab.
Taf.


357953

Rev.

01 0807

LH FRAME GROUP

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	014212	Screw	450 31	661163	L.H. rear shield
2	461409	L.H. side shield	500	661162	L.H. rear shield
3	014082	Screw	550	661161	L.H. rear shield
4	011004	Grower	32	923505	Spring
5	461456	Protection	33	002014	Split pin
6	014254	Screw	34	423558	Pivot
7	014149	Screw	35	010012	Washer
8	011002	Grower	36	923587	Support
9	461027	L.H. side clod bumper	37	010009	Washer
10	411860	Plate	38	004073	Nut
450 11	423627	Pivot	39	461471	Handle wrench
500	423628	Pivot	40	412596	Arm
550	423629	Pivot	41	014229	Screw
12	004004	Nut	42	014213	Screw
13	014285	Screw	43	004035	Nut
450 14	661183	L.H. frame	44	423557	Spring
500	661182	L.H. frame	45	423248	Bushing
550	661181	L.H. frame	46	423868	Pivot
15	010006	Washer	47	013011	Pin
16	623572	U-bolt	48	004030	Nut
17	008007	Grease nipple	49	011003	Grower
18	004072	Nut	50	423560	Support
19	611427	Plate	51	422529	Adjusting bar
20	014084	Screw	52	014145	Screw
21	611409	Spacer	53	411524	Hinge
22	014019	Screw	54	014257	Screw
23	014199	Screw	55	014011	Screw
24	471442	Screw	56	011004	Grower
25	461108	L.H. side shield	57	412376	Central blade
26	661145	Pivot	58	011036	Washer
27	423769	Bush			
28	014382	Screw			
29	461318	L.H. extension			
30	004079	Nut			



RH FRAME GROUP

Tav.
Tab.
Taf.**357954**

Rev.

01 0907

RH FRAME GROUP


Tav.
Tab.
Taf.

357954

Rev.

01 0907

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	014212	Screw	450 31	661173	R.H. rear shield
2	461411	R.H. side shield	500	661172	R.H. rear shield
3	014082	Screw	550	661171	R.H. rear shield
4	011004	Grower	32	923505	Spring
5	461455	Protection	33	002014	Split pin
6	014254	Screw	34	423558	Pivot
7	014149	Screw	35	010012	Washer
8	011002	Grower	36	923587	Support
9	461026	R.H. side clod bumper	37	010009	Washer
10	411860	Plate	38	004073	Nut
450 11	423627	Pivot	39	461471	Handle wrench
500	423628	Pivot	40	412596	Arm
550	423629	Pivot	41	014229	Screw
12	004004	Nut	42	014213	Screw
13	014182	Screw	43	004035	Nut
450 14	661193	R.H. frame	44	423557	Spring
500	661192	R.H. frame	45	423248	Bushing
550	661191	R.H. frame	46	423868	Pivot
15	010006	Washer	47	013011	Pin
16	623572	U-bolt	48	004030	Nut
17	008007	Grease nipple	49	011003	Grower
18	004072	Nut	50	423560	Support
19	611427	Plate	51	422529	Adjusting bar
20	014084	Screw	52	014145	Screw
21	611409	Spacer	53	411524	Hinge
22	014019	Screw	54	014257	Screw
23	014199	Screw	55	014011	Screw
24	471442	Screw	56	011004	Grower
25	461109	R.H. side shield	57	412376	Central blade
26	661145	Pivot	58	011036	Washer
27	423769	Bush			
28	014382	Screw			
29	461317	R.H. extension			
30	004079	Nut			



CENTRE FRAME

Tav.
Tab.
Taf.

357955

Rev.

01 0907


CENTRE FRAME

Tav.
Tab.
Taf.**357955**

Rev.

01**0907**

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	014007	Screw	34	004055	Nut
2	011002	Grower	35	723630	Pivot
3	612727	Flange	36	008001	Grease nipple
4	099140	Guard	37	005006	Ring nut
5	471441	Housing	38	611414	Hook
6	011005	Grower	39	005007	Ring nut
7	014326	Screw	40	661104	Third point
8	623698	Pivot	41	612943	Shim
9	613107	Bushing	42	011032	Grower
10	008005	Grease nipple	43	01004	Washer
11	661101	Swinging arm (cat.III)	44	411428	Support
	661111	Swinging arm (cat.III)	45	014001	Screw
12	723606	Pivot	46	411429	Protection
13	013011	Pin	47	971646	Bar
14	621735	Pivot			
15	005008	Ring nut			
16	623699	Pivot			
17	004069	Nut			
18	004084	Nut			
19	462172	Bar connection			
20	027006	Bar			
21	027007	Number plate holder			
22	027002	Reflector			
23	027003	Left Light			
24	612941	Plate			
25	014149	Screw			
26	027005	Power supply wire			
27	027004	Right light			
28	613128	Pivot			
29	661149	Bar			
30	523652	Drive shaft hook			
31	611728	Flask			
32	010023	Washer			
33	014005	Screw			



LH CAGE ROLLER Ø 500


LH CAGE ROLLER Ø 500

Tav.
Tab.
Taf.**357160**

Rev.

00**0206**

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	011004	Grower	30	014145	Screw
2	411529	Plate	31	011003	Grower
3	423833	Spacer	32	014192	Screw
4	014082	Screw	33	004072	Nut
5	014019	Screw	34	661402	Plate
6	014398	Screw	450	998231	Cage roller
7	004004	Nut	500	998232	Cage roller
8	423769	Bush	550	998233	Cage roller
9	014399	Screw			
10	423791	L.H. Attach. arm fulcrum lug			
11	014004	Screw			
12	010006	Washer			
13	010002	Washer			
450	14	661123			
500		661122			
550		661121			
15	611436	Arm			
16	612372	Plate			
17	013019	Pin			
18	014254	Screw			
19	661401	Stub axle			
20	004030	Nut			
450	21	961951			
500		961952			
550		961953			
22	004054	Nut			
23	661403	Bush			
24	462011	Arm			
25	099018	Dust cover			
26	008005	Grease nipple			
27	421604	Support			
28	003051	Bearing			
29	001006	Stop ring			



RH CAGE ROLLER Ø 500

Tav.
Tab.
Taf.**357161**

Rev.

00 0206


RH CAGE ROLLER Ø 500

Tav.
Tab.
Taf.**357161**

Rev.

00**0206**

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	011004	Grower	30	014145	Screw
2	411528	Plate	31	011003	Grower
3	423833	Spacer	32	014192	Screw
4	014082	Screw	33	004072	Nut
5	014019	Screw	34	661402	Plate
6	014398	Screw		998231	Cage roller
7	004004	Nut		998232	Cage roller
8	423769	Bush		998233	Cage roller
9	014399	Screw			
10	423790	R.H. Attach. arm fulcrum lug			
11	014004	Screw			
12	010006	Washer			
13	010002	Washer			
450	14	661133			
500		661132			
550		661131			
15	661141	Arm			
16	612372	Plate			
17	013019	Pin			
18	014254	Screw			
19	661401	Stub axle			
20	004030	Nut			
450	21	961951			
500		961952			
550		961953			
22	004054	Nut			
23	661403	Bush			
24	411470	Arm			
25	099018	Dust cover			
26	008005	Grease nipple			
27	421604	Support			
28	003051	Bearing			
29	001006	Stop ring			



LH SPIKES ROLLER Ø 560


LH SPIKES ROLLER Ø 560

Tav.
Tab.
Taf.**357162**

Rev.

00**0206**

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	011004	Grower	30	014145	Screw
2	411529	Plate	31	011003	Grower
3	423833	Spacer	32	014192	Screw
4	014082	Screw	33	004072	Nut
5	014019	Screw	34	661406	Plate
6	014398	Screw	35	612372	Plate
7	004004	Nut	36	913704	Tine (to be welded)
8	423769	Bush	37	623750	U bolt
9	014399	Screw	38	961851	Scratcher support
10	423791	L.H. Attach. arm fulcrum lug		961852	Scratcher support
11	014004	Screw		961853	Scratcher support
12	010006	Washer	39	961818	Scraper
13	010002	Washer		998271	Spikes roller
450 14	661123	Bar		998272	Spikes roller
500	661122	Bar		998273	Spikes roller
550	661121	Bar			
15	411470	Arm			
16	911602	Plate			
17	013019	Pin			
18	014145	Screw			
19	661401	Stub axle			
20	004101	Nut			
450 21	961991	Spikes roller			
500	961992	Spikes roller			
550	961993	Spikes roller			
22	004054	Nut			
23	661403	Bush			
24	462011	Arm			
25	099018	Dust cover			
26	008005	Grease nipple			
27	421604	Support			
28	003051	Bearing			
29	001006	Stop ring			



RH SPIKES ROLLER Ø 560

Tav.
Tab.
Taf.**357163**

Rev.

00 0206


RH SPIKES ROLLER Ø 560

Tav.
Tab.
Taf.**357163**

Rev.

00**0206**

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	011004	Grower	30	014145	Screw
2	411528	Plate	31	011003	Grower
3	423833	Spacer	32	014192	Screw
4	014082	Screw	33	004072	Nut
5	014019	Screw	34	661406	Plate
6	014398	Screw	35	612372	Plate
7	004004	Nut	36	913704	Tine (to be welded)
8	423769	Bush	37	623750	U bolt
9	014399	Screw	38	961851	Scratcher support
10	423790	L.H. Attach. arm fulcrum lug		961852	Scratcher support
11	014004	Screw		961853	Scratcher support
12	010006	Washer	39	961818	Scraper
13	010002	Washer		998271	Spikes roller
450 14	661133	Bar		998272	Spikes roller
500	661132	Bar		998273	Spikes roller
550	661131	Bar			
15	462014	Arm			
16	911602	Plate			
17	013019	Pin			
18	014145	Screw			
19	661401	Stub axle			
20	004101	Nut			
450 21	961991	Spikes roller			
500	961992	Spikes roller			
550	961993	Spikes roller			
22	004054	Nut			
23	661403	Bush			
24	411470	Arm			
25	099018	Dust cover			
26	008005	Grease nipple			
27	421604	Support			
28	003051	Bearing			
29	001006	Stop ring			



LH PACKER ROLLER Ø 555


Tav.
Tab.
Taf.**357164**

Rev.

00 0206

LH PACKER ROLLER Ø 555

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	011004	Grower	30	014145	Screw
2	411529	Plate	31	011033	Grower
3	423833	Spacer	32	014192	Screw
4	014082	Screw	33	004072	Nut
5	014019	Screw	34	661402	Plate
6	014398	Screw	35	612372	Plate
7	004004	Nut	36	412782	Tine (to be welded)
8	423769	Bush	37	961911	Scratcher support
9	014399	Screw		961912	Scratcher support
10	423791	L.H. Attach. arm fulcrum lug		961913	Scratcher support
11	014004	Screw	38	014386	Screw
12	010006	Washer	39	911601	Scraper
13	010002	Washer	40	004003	Nut
450	661123	Bar	41	014214	Screw
500	661122	Bar	42	911629	Scraper
550	661121	Bar	450	998241	Packer roller
15	411470	Arm	500	998242	Packer roller
16	911630	Scraper	550	998243	Packer roller
17	013019	Pin			
18	014145	Screw			
19	661401	Stub axle			
20	004084	Nut			
450	961921	Packer roller			
500	961922	Packer roller			
550	961923	Packer roller			
22	004054	Nut			
23	661403	Bush			
24	462011	Arm			
25	099018	Dust cover			
26	008005	Grease nipple			
27	421604	Support			
28	003051	Bearing			
29	001006	Stop ring			



RH PACKER ROLLER Ø 555

Tav.
Tab.
Taf.**357165**

Rev.

00 0206


RH PACKER ROLLER Ø 555

Tav.
Tab.
Taf.**357165**

Rev.

00 0206

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	011004	Grower	30	014145	Screw
2	423833	Spacer	31	011033	Grower
3	423833	Spacer	32	014192	Screw
4	014082	Screw	33	004072	Nut
5	014019	Screw	34	661402	Plate
6	014398	Screw	35	612372	Plate
7	004004	Nut	36	412782	Tine (to be welded)
8	423769	Bush	37	961911	Scratcher support
9	014399	Screw		961912	Scratcher support
10	423790	R.H. Attach. arm fulcrum lug		961913	Scratcher support
11	014004	Screw	38	014386	Screw
12	010006	Washer	39	911601	Scraper
13	010002	Washer	40	004003	Nut
450	14	661133	41	014214	Screw
500		661132	42	911629	Scraper
550		661131		998241	Packer roller
15	462014	Arm		998242	Packer roller
16	911630	Scraper		998243	Packer roller
17	013019	Pin			
18	014145	Screw			
19	661401	Stub axle			
20	004084	Nut			
450	21	961921			
500		961922			
550		961923			
22	004054	Nut			
23	661403	Bush			
24	411470	Arm			
25	099018	Dust cover			
26	008005	Grease nipple			
27	421604	Support			
28	003051	Bearing			
29	001006	Stop ring			



LH SPIRAL ROLLER Ø 470

Tav.
Tab.
Taf.

357166


Rev.

00

0206

LH SPIRAL ROLLER Ø 470

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	011004	Grower	28	003051	Bearing
2	411529	Plate	29	001006	Stop ring
3	423833	Spacer	30	014145	Screw
4	014082	Screw	31	011003	Grower
5	014019	Screw	32	014192	Screw
6	014398	Screw	33	004072	Nut
7	004004	Nut	34	661402	Plate
8	423769	Bush	450	998281	Spiral roller
9	014399	Screw	500	998282	Spiral roller
10	423791	L.H. Attach. arm fulcrum lug	550	998283	Spiral roller
11	014004	Screw			
12	010006	Washer			
13	010002	Washer			
450	14	661123			
500		661122			
550		661121			
15	411470	Arm			
16	612372	Plate			
17	013019	Pin			
18	014145	Screw			
19	661401	Stub axle			
450	20	961821			
500		961822			
550		961823			
450	21	961981			
500		961982			
550		961983			
22	004054	Nut			
23	661403	Bush			
24	462011	Arm			
25	099018	Dust cover			
26	008005	Grease nipple			
27	421604	Support			



RH SPIRAL ROLLER Ø 470


RH SPIRAL ROLLER Ø 470

Tav.
Tab.
Taf.**357167**

Rev.

00 0206

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	011004	Grower	28	003051	Bearing
2	411528	Plate	29	001006	Stop ring
3	423833	Spacer	30	014145	Screw
4	014082	Screw	31	011003	Grower
5	014019	Screw	32	014192	Screw
6	014398	Screw	33	004072	Nut
7	004004	Nut	34	661402	Plate
8	423769	Bush		998281	Spiral roller
9	014399	Screw		998282	Spiral roller
10	423790	R.H. Attach. arm fulcrum lug		998283	Spiral roller
11	014004	Screw			
12	010006	Washer			
13	010002	Washer			
450	14	661133			
500		661132			
550		661131			
15	661141	Arm			
16	612372	Plate			
17	013019	Pin			
18	014145	Screw			
19	661401	Stub axle			
450	20	961821			
500		961822			
550		961823			
450	21	961981			
500		961982			
550		961983			
22	004054	Nut			
23	661403	Bush			
24	411470	Arm			
25	099018	Dust cover			
26	008005	Grease nipple			
27	421604	Support			



HYDRAULIC SYSTEM FOR LIFTING

HYDRAULIC SYSTEM FOR LIFTING

Tav.
Tab.
Taf.


349555

Rev.

00

0304


RIF.	N. CODICE	DENOMINATION	
1	022082	Shap-on coupling	
2	022087	Washer	
3	023178	Hose	
4	023119	Hose	
5	022130	Connection	
6	004072	Nut	
7	671777	Complete jack	
8	014192	Screw	
9	023184	Hose	
10	022129	Connection	
11	021058	Stop valve	
12	022175	Screw	
13	022086	Washer	
14	621740	Hose	
15	022070	Screw	
16	671816	Complete jack	
17	621721	Hose	
18	014032	Screw	
19	010015	Washer	
20	462265	Connection block	
21	022120	Connection	

**FLOATING SYSTEM**

FLOATING SYSTEM

Tav. Tab. Taf.	349556	Rev.	00	0304
----------------------	---------------	------	-----------	-------------

RIF.	N. CODICE	DENOMINATION
1	022166	Screw
2	022151	Pipe fitting
3	021181	Hose
4	022129	Connection
5	021172	Tap
6	022086	Washer
	971760	Floating system



HYDRAULIC SYSTEM FOR ROLLER LIFTING

Tav.
Tab.
Taf.

357580

Rev.

00 0206


HYDRAULIC SYSTEM FOR ROLLER LIFTING

Tav.
Tab.
Taf.**357580**

Rev.

00**0206**

RIF.	N. CODICE	DENOMINATION	
1	022082	Shap-on coupling	
2	022087	Washer	
3	023178	Hose	
4	022129	Connection	
450	5	023154	Hose
500		023154	Hose
550		023152	Hose
6	021073	Flow divider	
7	462265	Connection block	
8	023153	Hose	
9	022175	Screw	
10	022070	Screw	
11	022120	Connection	
12	021094	Stop valve	
13	004072	Nut	
14	022178	Connection	
15	471444	Complete jack	
16	023152	Hose	
17	014398	Screw	
18	621736	Hose	
19	022086	Washer	
20	014122	Screw	



HYDRAULIC RAMS KIT FOR TAILGATE ADJUSTMENT


HYDRAULIC RAMS KIT FOR TAILGATE ADJUSTMENT

Tav.
Tab.
Taf.**350560**

Rev.

00**0304**


RIF.	N. CODICE	DENOMINATION
1	022082	Shap-on coupling
2	022087	Washer
3	023064	Hose
4	022085	Washer
5	022104	Connection
6	022088	Connection
7	014307	Screw
8	021092	Stop valve
9	004073	Nut
10	010009	Washer
11	923587	Support
12	923505	Spring
13	010012	Washer
14	971525	Complete jack
15	022086	Washer
16	023193	Hose
17	022175	Screw
	971769	Hydraulic rams kit



COOLING KIT

COOLING KIT

RIF.	N. CODICE	DENOMINATION	RIF.	N. CODI	DENOMINATION
1	027001	Cable	34	423605	Pulley
2	021055	Exchange	35	223405	Spacer
3	004055	Nut	36	021083	Trasmission belt
4	461107	Cover	37	423606	Pulley
5	022087	Washer	38	014320	Screw
6	023182	Hose	39	014007	Screw
7	022030	Capstan screw	40	011032	Grower
8	014001	Screw	41	010004	Washer
9	661110	Air duct	42	014026	Screw
10	099124	Screw shock absorber		971057	Cooling kit
11	010023	Washer			
12	023086	Connection			
13	021061	Thermostat			
14	023115	Hose			
15	022119	Connection			
16	021052	Filter			
17	014005	Screw			
18	011001	Grower			
19	022121	Connection			
20	023175	Hose			
21	022120	Connection			
22	023181	Hose			
23	022159	Connection			
24	004083	Nut			
25	010015	Washer			
26	021079	Hub			
27	021078	Support			
28	021051	Pump			
29	014393	Screw			
30	461107	Support			
31	014306	Screw			
32	011009	Grower			
33	010035	Washer			



CONVEYOR DISC


CONVEYOR DISC

Tav.
Tab.
Taf.**138110**

Rev.

01 0202

RIF.	N. CODICE	DENOMINATION
1	004063	Nut
2	010006	Washer
3	923690	Plate
4	014241	Screw
5	923511	U bolt
6	961693	Support
7	010009	Washer
8	002014	Split pin
9	004080	Nut
10	015008	Cover
11	961697	Support
12	003087	Bearing
13	002013	Split pin
14	961524	Drive hub
15	099017	Dust cover
16	001031	Stop ring
17	003073	Bearing
18	008002	Grease nipple
19	011002	Washer
20	004002	Nut
21	014155	Screw
22	099030	Disc
23	961696	Support
	971511	Front conveyor disc




LIFTING JACK

Tav. Tab. Taf.	124202	Rev.	01	0699
----------------------	--------	------	----	------

LIFTING JACK

Tav. Tab. Taf.	124202	Rev.	01	0699
----------------------	---------------	------	-----------	-------------

RIF.	N. CODICE	DENOMINATION
1	008007	Grease nipple
2	662541	Cylinder
3	099066	Bushing
4	004056	Nut
5	007190	Gasket
6	623805	Piston
7	007181	Gasket
8	007192	Gasket
9	022126	Ring
10	623802	Cylinder head
11	007193	Gasket
12	007194	Gasket
13	662540	Rod
14	002017	Split pin
15	671776	Complete jack

**BLOCKING HOOK COMMANDING JACK**


BLOCKING HOOK COMMANDING JACK

Tav.
Tab.
Taf.**124206**

Rev.

01 0699

RIF.	N. CODICE	DENOMINATION
1	623611	Fork
2	004040	Nut
3	010006	Washer
4	423557	Spring
5	623810	Rod
6	007198	Gasket
7	007196	Gasket
8	623809	Stem guide
9	007197	Gasket
10	007191	Gasket
11	623808	Piston
12	004087	Nut
13	662544	Hose
14	671777	Complete jack




ROLLER ADJUSTMENT JACK

Tav.	120221	Rev.	00	1000
Tab.				
Taf.				

ROLLER ADJUSTMENT JACK

Tav. Tab. Taf.	120221	Rev.	00	1000
----------------------	---------------	------	-----------	-------------

RIF.	N. CODICE	DENOMINATION
1	623818	Fork
2	011010	Grower
3	004027	Nut
4	662543	Ring nut
5	007177	Gasket
6	007178	Gasket
7	662545	Guide
8	007168	Gasket OR
9	423239	Rod
10	423197	Half piston
11	007165	Gasket
12	007058	Gasket OR
13	423196	Piston
14	004072	Nut
15	461464	Cylinder
16	471444	Complete jack




LOOSENING TIME

Tav.	120650	Rev.	02	1002
Tab.				
Taf.				

LOOSENING TINE

Tav. Tab. Taf.	120650	Rev.	02	1002
----------------------	---------------	------	-----------	-------------

RIF.	N. CODICE	DENOMINATION
1	004009	Nut
2	010006	Washer
3	461358	Support
4	461095	Hitch
5	004003	Nut
6	011003	Grower
7	961549	Ripper leg
8	014181	Screw
9	923511	U bolt
10	823560	Blade
11	014268	Screw
12	014273	Screw
13	014078	Screw
14	411713	Plate
	971761	Loosening tine kit



SAFETY PROTECTION

Tav. Tab. Taf.	357168	Rev.	00	0206
----------------------	---------------	------	-----------	-------------

SAFETY PROTECTION

Tav.
Tab.
Taf.**357168**

Rev.

00**0206**

RIF.	N. CODICE	DENOMINATION
450	1	462003 Protection
500		462004 Protection
550		462005 Protection
	2	913022 U bolt
	3	010004 Washer
	4	004066 Nut
450		978722 Protection
500		978723 Protection
550		978724 Protection