
**BED MAKER** 

#### **ABOUT**

The ScanStone bed maker range adopts the classic ScanStone style body and ploughs, leaving a wide bottom trench for the stones and clods to lie in as it pulls through the ground. The auto reset model negates the use of shearbolts, using heavy duty rams, perfect for stonier conditions.







Durable machine which could go on the back of our bed tiller or straight in behind the tractor if we didn't need to bed till. It was a big cost-saving.



This bed maker is available with the option of **Chateau-style ploughs.** See page 43 for details






# **BED MAKING**

#### **THE PROCESS**

The bed maker is designed to go into pre-cultivated ground, both to create beds for destoning and aeriating the soil. It is key for the bed maker to get as much soil as possible out of the trench and into the bed. This gives the destoner the maximum potential.



#### THE CONFIGURATIONS

ScanStone bed makers are available in 2-body, 3-body or 4-body configurations. The 4-body is available in either a heavy-duty or superlight version. Bed makers can be equipped with ScanStone-style mouldboards, or Chateau-style ploughs (which create a steeper, wider bed). The standard ScanStone-style mouldboards are available with a shearbolt, auto-reset or dual action protection, depending on soil conditions and stone content.


The Chateau-style ploughs are available with shearbolt or auto-reset protection. This plough is used in lighter soil conditions where it is achievable to get a castellated bed for an even intake into the destoner. The chateau-style ploughs maintain the classic ScanStone wide bottom trench, which also eliminates to a degree the need to constantly guide the destoner tractor.


# **AR+ MODELS**

The ScanStone AR+ models negate the need for additional shearbolt protection. This auto reset system has a double pivot point allowing the beam to pivot and also the body to pivot as the plough strikes a stone or tree root. There is enough stroke in the hydraulic cylinder for the plough to reset in both instances and enough pressure in the accumulator for the plough to reset back to the preset depth.



#### THE CONFIGURATIONS





1814mm

1050 kg

110 hp


Transport Width 3.08m Transport Height 2.28m **UN-3844 FD SB** *3 Body* 

1650-2050mm 1650-2050mm

1650-2050mm 1650-2050mm

Shearbolt Folding Frame

3FD



250 hp

2800 kg

9


1.65-2.05m 1.65-2.05m 1.65-2.05m



#### **NUMBER OF PLOUGHS**

The ScanStone bed former range consists of 2 plough, 3 plough and 4 plough models. The ploughs are adjustable from 1.65-2.05m. The number of ploughs depends on the amount of horsepower available, and the area desired to achieve in one pass.

- **UN-3842** 2 Ploughs
- **UN-3844** 3 Ploughs
- **UN-3845** 4 Ploughs



#### **FRAME TYPE**

ScanStone bed formers are available with fixed or folding frames.

- **FX** Fixed
- FD Folding
- **WF** Wing-Folding
- Centre-Folding



#### **PLOUGH PROTECTION**

Depending on soil conditions and stone content, the ScanStone bed formers can be equipped with shearbolt, auto reset or auto reset plus (non-stop) protection systems. The auto reset version uses hydraulic rams when large stones are encountered, but additionally has a shearbolt system which protects the body when immovable objects are hit.

- SB Shearbolt
- Auto Reset AR
- AR+ Auto Reset Plus (Non-Stop)

2	D	0	D	1
_	D	u	v	т

**UN-3842 SB** 2 Body Shearbolt UN-3842 AR 2 Body Auto Reset UN-3842 AR+ 2 Body AR+ (Non-Stop)



**UN-3844 FX SB** 3 Body Fixed Shearbolt **UN-3844 FX AR** 3 Body Fixed Auto Reset UN-3844 FX AR+ 3 Body Fixed AR+ (Non-Stop)



**UN-3844 FD SB** *3 Body Folding Shearbolt* **UN-3844 FD AR** 3 Body Folding Auto Reset UN-3844 FD AR+ 3 Body Folding AR+ (Non-Stop) 3 Body Folding AR+ Terra **UN-3844 TERRA** 

# 4 BODY Wing-Folding

**UN-3845 WF SB** 4 Body Wing-Folding Shearbolt **UN-3845 WF AR** 4 Body Wing-Folding Auto Reset UN-3845 WF AR+ 4 Body Wing-Folding AR+ (Non-Stop)

#### **4 BODY** Centre-Folding

UN-3845 CF AR+ 4 Body Centre-Folding AR+ (Non-Stop)







#### TRACK WIDTH SETTING

Distance between centre to centre of plough.



- **SET-001** 1.50 m
- **SET-002** 1.60 m
- **SET-003** 1.65 m
- **SET-004** 1.70 m
- **SET-005** 1.80 m Default
- **SET-006** 1.85 m
- **SET-007** 2.00 m

St	anda	rd	
3	3T	4WF	4CF



# **CLASSIC STYLE PLOUGHS**

Leave a wide bottom trench for the stones and clods to lie in. Leaves a bed that is quicker to dry.

KIT-1100

Standard						
2	3	3T	4WF	4CF		



#### **CHATEAU STYLE PLOUGHS**

Different shape of body to leave a steeper trench. See **page 24** for details.

- **KIT-1109** *SB/AR (Per plough)*
- **KIT-1116** AR+ (*Per plough*)


		(	Optio	n	
	2		3T	4WF	4CF



#### **DISC-STYLE HYDRAULIC MARKER KIT**

Disc-style markers leave an accurate scribe in the soil giving the operator a useful guide on his return journey up the field, when not using GPS.

- KIT-1084 2 & 4 Body (Pair)
- **KIT-1080** *3 Body* (Pair)





#### POINT-STYLE HYDRAULIC MARKER KIT

Point-style markers are a less expensive option and virtually maintenance-free. Mainly used to assist the operator should be GPS fail.

• **KIT-1081** (*Pair*)







#### HYDRAULICALLY EXTENDABLE MARKER KIT

In conditions where GPS coverage may be limited, the hydraulic extendable markers provide centre marking while operating the ScanStone 4 body bed former with 4 ploughs down. Comes with a choice of disc or point.

• **BOM-0337** (*Pair*)





#### **STABILISER FINS**

Stabiliser fins act as as rudder to the plough to improve stability during work. Fins are not compatible with Chateau ploughs.

• **KIT-1102** (*Each*)





# MANUAL DEPTH WHEEL KIT

To act as a depth guide and keep the ploughs from digging in too deep.

• **KIT-1127** 15"

• KIT-1122 18"

Option / Standard					
2	3	3T	4WF	4CF	
2	3	3T	4WF	4CF	



#### **HYDRAULIC DEPTH WHEEL KIT**

To act as a depth guide and keep the ploughs from digging in too deep.

• **BOM-1128** *15"* 

• **BOM-1123** 18" (in lieu)



Option						
2	3	3T	4WF	4CF		
2	3	3T	4WF	4CF		



#### **PARALLEL LINKAGE KIT**

For keeping the ploughs level when working in half depths.

BOM-0315







#### **LARGE TAIL PIECES**

Attached at the top of the mouldboard, the tail pieces keep the side wall of the bed in position in deeper and heavier conditions. Not compatible with Chateau ploughs.

• BOM-0371 Pair



Option						
2		3T	4WF	4CF		



# **EASY DUTY CULTIVATOR TINE**

To break up the soil before the ploughs engage.

KIT-1114 Each



	(	Optio	n	
2		3T	4WF	4CF



# **HEAVY DUTY CULTIVATOR TINE**

To break up the soil before the ploughs engage.

KIT-1130 Each



	(	Optio	n	
2		3T	4WF	4CF



# **CULTIVATOR TINE TOOLBAR**

This removable toolbar is made up of four spring-loaded tines, which are situated forward of the ridging ploughs, allowing the soil to flow through the system more effectively.

• **BOM-0318** Each



Option / Standard

2 3 3T 4WF 4CF



#### **TOOL BOX**

Useful for storing tools, spare parts and other maintenance essentials.

BOM-0319





# **UNIQUE PARTS LIST**

Each individual bed former comes as standard with a unique parts manual which features the exact specifications and equipment which is mounted on the machine before it leaves the factory. Customers are able to quote their serial number to their parts provider, to ensure that the correct parts are ordered. Not only does this speed up the ordering process, but avoids mistakes.

Standard
2 | 3 | 3T | 4WF | 4CF



# **USER MANUAL / MACHINE STICKERS**

The country of use kit consists of a hard-copy of the user manual and machine stickers in the country's spoken language.

- English (Standard)
- French

Standard
2 | 3 | 3T | 4WF | 4CF





# **GALLERY 5** BED TILLERS 1.8M SINGLE BED TILLER WITH 2 BODY BED MAKER 3.6M FOLDING BED TILLER WITH 2 BODY BED MAKER